



Fejemaskine HF-PN 818-xxx-000



## Fejemaskine HF-PN

Pos.	Benævnelse	Description	Beschreibung	Stk.	Varenummer
1	Hydraulikslange 1/2" kundetilpasset	Hydraulic hose for motor	Hyd.Schlauch Motor	1	818-130-401
2	Hydraulikslange 1/2" kundetilpasset	Hydraulic hose for motor	Hyd.Schlauch Motor	1	818-130-402
3	Sætskrue	Set screw	Stahlsetzschraube	8	329-112-025
4	Sideplade - Venstre	Side plate left	Tragearm	1	818-130-202
5	Sætskrue	Set screw	Stahlsetzschraube	4	329-116-050
6	Bæreramme HF-PN 1100	Supportframe HF-PN 1100	Hauptrahmen HF-PN 1100	1	818-110-201
6	Bæreramme HF-PN 1200	Supportframe HF-PN 1200	Hauptrahmen HF-PN 1200	1	818-120-201
6	Bæreramme HF-PN 1300	Supportframe HF-PN 1300	Hauptrahmen HF-PN 1300	1	818-130-201
6	Bæreramme HF-PN 1400	Supportframe HF-PN 1400	Hauptrahmen HF-PN 1400	1	818-140-201
6	Bæreramme HF-PN 1500	Supportframe HF-PN 1500	Hauptrahmen HF-PN 1500	1	818-150-201
6	Bæreramme HF-PN 1600	Supportframe HF-PN 1600	Hauptrahmen HF-PN 1600	1	818-160-201
6	Bæreramme HF-PN 1700	Supportframe HF-PN 1700	Hauptrahmen HF-PN 1700	1	818-170-201
6	Bæreramme HF-PN 1800	Supportframe HF-PN 1800	Hauptrahmen HF-PN 1800	1	818-180-201
6	Bæreramme HF-PN 2000	Supportframe HF-PN 2000	Hauptrahmen HF-PN 2000	1	818-200-201
7	Låsemøtrik	Locking Nut	Sicherungsmutter	1	331-101-024
8	Rørstift	Pipe split	Rohrstift	4	338-308-040
9	Ledhoved GIR 25 DO	Rod	Gelenklager	1	354-300-031
10	Hydraulikcylinder	Hydraulic cylinder	Zylinder	1	301-300-019
11	Hydraulikslange 1/4" kundetilpasset	Hydraulic hose for cylinder	Hyd.Schlauch Zylinder	1	818-130-403
12	Hydraulikslange 1/4" kundetilpasset	Hydraulic hose for cylinder	Hyd.Schlauch Zylinder	1	818-130-404
13	Indskruining	Fitting	Verschraubung	2	363-300-153
14	Beslag for overplade venstre	Bracket left for topplate	Winkelbeschlag für Topplatte	1	818-130-540
15	Overplade HF-PN 1100	Top plate HF-PN 1100	Deckschirm HF-PN 1100	1	818-110-533
15	Overplade HF-PN 1200	Top plate HF-PN 1200	Deckschirm HF-PN 1200	1	818-120-533
15	Overplade HF-PN 1300	Top plate HF-PN 1300	Deckschirm HF-PN 1300	1	818-130-533
15	Overplade HF-PN 1400	Top plate HF-PN 1400	Deckschirm HF-PN 1400	1	818-140-533
15	Overplade HF-PN 1500	Top plate HF-PN 1500	Deckschirm HF-PN 1500	1	818-150-533
15	Overplade HF-PN 1600	Top plate HF-PN 1600	Deckschirm HF-PN 1600	1	818-160-533
15	Overplade HF-PN 1700	Top plate HF-PN 1700	Deckschirm HF-PN 1700	1	818-170-533
15	Overplade HF-PN 1800	Top plate HF-PN 1800	Deckschirm HF-PN 1800	1	818-180-533

## Fejemaskine HF-PN

15	Overplade HF-PN 2000	Top plate HF-PN 2000	Deckschirm HF-PN 2000	1	818-200-533
16	Beslag for overplade	Ajustment for top plate	Einstellung für Topplatte	2	818-130-531
17	Sætskrue	Set screw	Stahlsetzschraube	8	329-108-035
18	Beslag for overplade højre	Bracket right for topplate	Winkelbeschlag für Topplatte	1	818-130-541
19	Afstiver for overplade.	Support for top plate	Schirmträger	2	818-130-542
20	Sideplade højre	Side plate right	Tragearm	1	818-130-524
21	Sætskrue	Set screw	Stahlsetzschraube	4	329-112-040
22	Flangeleje Ø35	Flanged housing unit	Flanschlager	1	354-200-025
23	Pendlearm	Pendling arm	Pendelarm	1	810-100-218
24	Bundplade for svingophæng	Plate for pendling suspension	Platte für zwischenrahmen	1	818-130-203
25	Maskinbolt	Set screw	Stahlsetzschraube	4	328-116-050
26	Svingophæng HF-PN	Pendeling suspension	Zwischenrahmen	1	818-130-204
27	Støttehjul kpl.	Wheel complete	Radständer	2	803-200-132
28	Bøjle for fastspænding af støttehjul	Clamp for wheel	Klemme für radständer	4	803-200-234
29	Støtteben	Supporter	Stützbein	3	818-130-534
30	Rørsplit 10x60	Pipe split	Rohrstift	2	338-100-163
31	Sætskrue	Set screw	Stahlsetzschraube	3	329-108-025
32	Skive Ø9/Ø30	Washer	Scheibe	1	336-130-009
33	Medbringer aksel ø25	Carrier shaft	Achszapfen	1	810-100-528
34	Afstandsring for hydraulikmotor 15 mm	Spacer for motor 195cc	Distanzring motor 195cc	1	804-110-530
35	Endestop skive ved hydraulikmotor	End plate	Endplatte	1	818-130-535
36	Hydraulikmotor 195 cc	Motor 195 cc	Motor 195 cc	1	374-300-497
36	Hydraulikmotor 240 cc	Motor 240 cc	Motor 240 cc	1	374-300-498
37	Indskruining Ø15L udv x 7/8" UNF	Fitting	Verschraubung	2	363-300-556
38	Hydraulikrør-lang HF 1100	Hydraulic tube - long HF 1100	Hydraulikrohr - Lang HF 1100	1	818-110-566
38	Hydraulikrør-lang HF 1200	Hydraulic tube - long HF 1200	Hydraulikrohr - Lang HF 1200	1	818-120-566
38	Hydraulikrør-lang HF 1300	Hydraulic tube - long HF 1300	Hydraulikrohr - Lang HF 1300	1	818-130-566
38	Hydraulikrør-lang HF 1400	Hydraulic tube - long HF 1400	Hydraulikrohr - Lang HF 1400	1	818-140-566
38	Hydraulikrør-lang HF 1500	Hydraulic tube - long HF 1500	Hydraulikrohr - Lang HF 1500	1	818-150-566
38	Hydraulikrør-lang HF 1600	Hydraulic tube - long HF 1600	Hydraulikrohr - Lang HF 1600	1	818-160-566
38	Hydraulikrør-lang HF 1700	Hydraulic tube - long HF 1700	Hydraulikrohr - Lang HF 1700	1	818-170-566

## Fejemaskine HF-PN

38	Hydraulikrør-lang HF 1800	Hydraulic tube - long HF 1800	Hydraulikrohr - Lang HF 1800	1	818-180-566
38	Hydraulikrør-lang HF 2000	Hydraulic tube - long HF 2000	Hydraulikrohr - Lang HF 2000	1	818-200-566
39	Hydraulikrør-kort HF 1100	Hydraulic tube - short HF 1100	Hydraulikrohr - Kurz HF 1100	1	818-110-567
39	Hydraulikrør-kort HF 1200	Hydraulic tube - short HF 1200	Hydraulikrohr - Kurz HF 1200	1	818-120-567
39	Hydraulikrør-kort HF 1300	Hydraulic tube - short HF 1300	Hydraulikrohr - Kurz HF 1300	1	818-130-567
39	Hydraulikrør-kort HF 1400	Hydraulic tube - short HF 1400	Hydraulikrohr - Kurz HF 1400	1	818-140-567
39	Hydraulikrør-kort HF 1500	Hydraulic tube - short HF 1500	Hydraulikrohr - Kurz HF 1500	1	818-150-567
39	Hydraulikrør-kort HF 1600	Hydraulic tube - short HF 1600	Hydraulikrohr - Kurz HF 1600	1	818-160-567
39	Hydraulikrør-kort HF 1700	Hydraulic tube - short HF 1700	Hydraulikrohr - Kurz HF 1700	1	818-170-567
39	Hydraulikrør-kort HF 1800	Hydraulic tube - short HF 1800	Hydraulikrohr - Kurz HF 1800	1	818-180-567
39	Hydraulikrør-kort HF 2000	Hydraulic tube - short HF 2000	Hydraulikrohr - Kurz HF 2000	1	818-200-567
40	Vinkelskotgennemføring	Right angle bulkhead	Winkel Verschraubung	2	363-300-168
44	Håndtag for støttehjul	Handle for support wheel	Handgriff für Stützrad	1	803-200-109
45	Yderrør for støttehjul	OuterTube for support wheel	Aussenrohr für Stützrad	1	803-200-127
46	Axial-trykleje	Axial ball bearing	Axialkugellager	1	354-251-104
47	Spindel TR22	Spindle TR22	Spindel TR22	1	804-200-107
48	Inderrør for støttehjul	Inner tupe for support wheel	Innerrohr für Stützrad	1	804-200-106
49	Unbracobolt-konisk	Allen screw	Unbracobolzen	2	332-006-016
50	Hjulgaffel 8" navbredde 95mm	Wheel fork	Radgabel	1	373-200-105
51	Låsemøtrik	Locking Not	Sicherungsmutter	1	331-101-012
52	Stålbolt	Bolt	Maschinenschraube	1	328-112-130
53	Hjul Ø200 massiv	Wheel Ø200	Festgummirad Ø200	1	319-200-007
54	Rundhovedet unbracoskrue	Allen screw	Unbracobolzen	4	332-112-035
55	Motorskål FH-P	Motor end for brush rool	Schale für Kehrwalze	1	804-110-218
56	Medbringer	Driver flange	Mitnehmer	1	804-110-240
57	Kostevalse HF 1100	Brush roll HF 1100	Bürstewalze HF 1100	1	869-007-090
57	Kostevalse HF 1200	Brush roll HF 1200	Bürstewalze HF 1200	1	869-007-100
57	Kostevalse HF 1300	Brush roll HF 1300	Bürstewalze HF 1300	1	869-007-110
57	Kostevalse HF 1400	Brush roll HF 1400	Bürstewalze HF 1400	1	869-007-120
57	Kostevalse HF 1500	Brush roll HF 1500	Bürstewalze HF 1500	1	869-007-130
57	Kostevalse HF 1600	Brush roll HF 1600	Bürstewalze HF 1600	1	869-007-140

## Fejemaskine HF-PN

57	Kostevalse HF 1700	Brush roll HF 1700	Bürstewalze HF 1700	1	869-007-150
57	Kostevalse HF 1800	Brush roll HF 1800	Bürstewalze HF 1800	1	869-007-160
57	Kostevalse HF 2000	Brush roll HF 2000	Bürstewalze HF 2000	1	869-007-180
58	Bæreflange kpl.	Flanged bearing complete	Stützflansch	1	818-130-205
59	Unbracoskrue	Allen screw	Unbracobolzen	4	332-012-050
60	Distancering 7" HF 1100	Spacer HF 1100	Distanzring HF 1100	26	353-200-009
60	Distancering 7" HF 1200	Spacer HF 1200	Distanzring HF 1200	28	353-200-009
60	Distancering 7" HF 1300	Spacer HF 1300	Distanzring HF 1300	31	353-200-009
60	Distancering 7" HF 1400	Spacer HF 1400	Distanzring HF 1400	33	353-200-009
60	Distancering 7" HF 1500	Spacer HF 1500	Distanzring HF 1500	36	353-200-009
60	Distancering 7" HF 1600	Spacer HF 1600	Distanzring HF 1600	38	353-200-009
60	Distancering 7" HF 1700	Spacer HF 1700	Distanzring HF 1700	40	353-200-009
60	Distancering 7" HF 1800	Spacer HF 1800	Distanzring HF 1800	43	353-200-009
60	Distancering 7" HF 2000	Spacer HF 2000	Distanzring HF 2000	48	353-200-009
61	Børstering 7"- Ø600 HF 1100	Brush HF 1100	Polybørste HF 1100	28	353-200-010
61	Børstering 7"- Ø600 HF 1200	Brush HF 1200	Polybørste HF 1200	32	353-200-010
61	Børstering 7"- Ø600 HF 1300	Brush HF 1300	Polybørste HF 1300	33	353-200-010
61	Børstering 7"- Ø600 HF 1400	Brush HF 1400	Polybørste HF 1400	36	353-200-010
61	Børstering 7"- Ø600 HF 1500	Brush HF 1500	Polybørste HF 1500	37	353-200-010
61	Børstering 7"- Ø600 HF 1600	Brush HF 1600	Polybørste HF 1600	40	353-200-010
61	Børstering 7"- Ø600 HF 1700	Brush HF 1700	Polybørste HF 1700	42	353-200-010
61	Børstering 7"- Ø600 HF 1800	Brush HF 1800	Polybørste HF 1800	45	353-200-010
61	Børstering 7"- Ø600 HF 2000	Brush HF 2000	Polybørste HF 2000	49	353-200-010